

DAED *SPEAK AND DETH* MANUAL



1. **Pitch Shifter Tri-Switch (Down/Off/Up)**
2. **Pitch Shift Amount Knob**
3. **Dual Glitch Switches 1 and 2 (On/Off)**
4. **Distortion (On/Off)**
5. **Looping Audition Button and Freeze Switch (On/Off)**
6. **Secondary Looping Freeze Switch (On/Off)**
7. **Vibrato/Pitch Shift Touch Sensor**
8. **Crash Reset Button**



Modified by David Talento: LegionHWP@gmail.com
[Http://www.HelpWantedProductions.com](http://www.HelpWantedProductions.com) (all rights reserved)